

Quick Start Guide Koncentrik V2 APC

INST-QUAL-0037-IndC

General information:

- No focus adjustment: it's normal to see a blurry spot of light.
- Do a complete 360° turn of the connector during measurement.
- Holder must be well adjusted for connector (smooth unforced insertion but without any play)
- Connector plugged to the light source must be well aligned with light beam and well held.
 - Keep the focal plan unchanged during the rotation, so be sure that the connector is always fully inserted inside the holder.

Connect to external power supply light source



Check picture you need to have

